

# Instructions to convert shelves into coffin

## Shelves for Life

by William Warren

01.01.10

Step One. Dismantle shelves into parts and label each part.

Step Two. Join together the lid (A+B) and base (C+D) with sash clamps and PVA glue along the edge. You may need to make up wedges to help clamp the angled sides.

Step Three. Join together long side panels of the coffin from the four shelf boards with glue along edge. Remember, the widest board fits with the narrowest board and the two middle sizes fit together. Keep any surface holes away from joint and next to edges.

Step Five. Cut angles into the ends of the long sides and the head and shoulder panels. Angles are  $85^\circ$  at ①,  $57.5^\circ$  at ②, and  $77.5^\circ$  at ③.

Step Six. Glue and screw through all side panels to each other and onto the edge of the base panel.

Step Seven. Fill any unused holes and support structure if needed along joints and at angled corners.

Step Eight. Fill and screw down lid.

For more information go to [williamwarren.co.uk](http://williamwarren.co.uk)