

DO NOT
GLUE!

Instructions to assemble Shelves for Life

by William Warren 01.01.10

Step One. Accurately cut out the shapes and drill all screw holes (5mm or 3/16" drill bit) from 18mm (3/4") thick plywood, using the cutting list provided. Label each piece.

Step Two. Join uprights together with screws through panel A into the edge of panel C (and B to D). This is half the coffin lid joining to half the coffin base. Be sure to check the feet of the shelves are level to avoid wobble later.

Step Three. Join shelf/box section together by screwing through L+M into the edge of J, before screwing through the two smaller shelf boards H+G into L+M+J. Repeat for second shelf/box section (E,F,N,O+K). Be sure to centre the boxes in the shelves and keep shelf ends level with each other.

Step Four. Screw both upright sections to the shelf/box sections through panels A and B, with the largest shelf E at the bottom and the narrowest H at the top. Then screw through C+D into the shelves for stability.

For more information go to williamwarren.co.uk